

Flexxy measuring guide


How to measure your dog to determine dog crate size:

L = Nose to base of tail -> add at the least +7 cm !

H = Height at the withers -> add at the least +7 cm !

In case of doubt, always choose the bigger dog crate.

Dog breeds below are examples only. ALWAYS measure for yourself.



	Width (cm)	Length (cm)	Height (cm)	Pet breed (examples only, ALWAYS measure for yourself)
Flexxy Single				
XS	34,5	48,3	39,9	Cat or small dog
S	42,5	65,9	49,6	Cat or small dog
M	47,8	77,8	65,8	Nova Scotia Duck Tolling Retriever (Toller), Lagotto Romagnolo, Border Collie
M wide	55,6	75,2	64,2	Nova Scotia Duck Tolling Retriever (Toller), Lagotto Romagnolo, Border Collie
L	65	90,2	72,1	Airedale Terrier, Bull Terrier, Dalmatian, Golden Retriever, Husky, Labradoodle
Flexxy Double				
				Two dogs with separation wall 50/50
Double S	82,9	66	49,6	2x Beagle, Fox Terrier, Staffordshire Bull Terrier
Double M	93,5	78	65,8	2x Australian Shepherd, Lagotto Romagnolo, Border Collie, Pitbull Terrier
				Single use, separation wall removed